


Casambi Broadcast. Remote Installation

Casambi controller. It is recommended to adjust the minimum level of regulation to 5%. Driver and external interface required have to be ordered separately. Dimming range 20-100%.



Electrical

Emergency Without



Certification / Marking

